

Einbruchhemmung Forster unico XS



DIN ENV 1627

Stahl

	RC1	RC2	RC3	DIN L / DIN R
	FFB 411 - 1400 FFH 520 - 2400	FFB 411 - 1400 FFH 520 - 2400	–	
	FFB 411 - 1400 FFH 520 - 2400	FFB 411 - 1400 FFH 520 - 2400	–	
	SFB 411 - 1400 SFH 801 - 2400	SFB 411 - 1400 SFH 801 - 2400	–	
	FFB 411 - 1400 FFH 520 - 2400	FFB 411 - 1400 FFH 520 - 2400	–	
	FFB 411 - 1400 FFH 520 - 2400	FFB 411 - 1400 FFH 520 - 2400	–	
	SFB 411 - 1400 SFH 801 - 2400	SFB 411 - 1400 SFH 801 - 2400	–	
	FFB 411 - 1400 FFH 520 - 2400	FFB 411 - 1400 FFH 520 - 2400	–	
	FFB 411 - 1400 FFH 520 - 2400	FFB 411 - 1400 FFH 520 - 2400	–	
	SFB 411 - 1400 SFH 801 - 2400	SFB 411 - 1400 SFH 801 - 2400	–	
B x H unbegrenzt $b_{\max} \times h_{\max} 1500 \times 3000 / b_{\max} \times h_{\max} 3000 \times 1500$				

FFB = Flügelfalzbreite
 FFH = Flügelfalzhöhe
 SFB = Stulpfalzbreite
 SFH = Stulpfalzhöhe