

RF MONO REMOTE PUSH BUTTON

PROLED®



Installation mit Schrauben oder Magnet / installation with screws or magnet

Die PROLED RF MONO Funktaster ermöglichen in Verbindung mit dem RF PWM DIMMER 4-KANAL (Seite 695) das Dimmen und Schalten ohne großen Installationsaufwand.

- einfaches Dimmen und Schalten mittels PUSH DIM Funktion
- Jeder RF MONO Funktaster kann mit beliebig vielen RF PWM DIMMERN verbunden werden.
- Jeder RF PWM DIMMER kann von maximal 8 Funktasern gesteuert werden.
- 868 MHz, 20-30 m Übertragungsdistanz innerhalb von Räumen
- Installation mit Schrauben oder Magnet

The PROLED RF MONO remote push buttons can dim and switch in combination with the RF PWM DIMMER 4-CHANNEL (page 695) LED luminaires without intensive installation work.

- easy dimming and switching via PUSH DIM function
- each RF MONO remote push button can be connected to endless RF PWM DIMMER
- each RF PWM DIMMER can be controlled by max. 8 RF remote push buttons
- 868 MHz, 20-30 m distance of transmission indoors
- installation with screws or magnet

Technische Daten

Abmessungen (ø x h):	ø39 x 18 mm
Batterien (inklusive):	CR2025 (3 VDC)
Gewicht:	0,02 kg

Technical Data

Dimension (ø x h):	ø39 x 18 mm
Batteries (included):	CR2025 (3 VDC)
Weight:	0,02 kg

Zubehör / Accessories

Artikel-Nr. order code	Bezeichnung description
L51306	Batterie CR 2025, 3V (Lithium Knopfzelle) Battery CR 2025, 3V (Lithium coin cell)

Produkttypen / Product Type

Artikel-Nr. order code	Bezeichnung description
L513175S	RF MONO REMOTE PUSH BUTTON silber / silver
L513175W	RF MONO REMOTE PUSH BUTTON weiß / white